Vcore Upgrade Guide

Using HollyView APP to upgrade Vcore on iPhone

1. Use your phone to connect the wifi of the Vcore

(1)The wifi name of the Vcore is HLD_xxxxx,the default password is 12345678



(2)Or you can use the HollyView app to scan the QR code of the product to connect the wifi.



(3) Add new product and select Vcore.


09:49
5G
73
Home
My Devices
Vcore
WiFi:HLD_38224QA
Pyro S
WiFi:HLD_3322375
Vcore
MARS 400S PRO


WiFi:HLD_000FA8D
WiFi:HLD_E0008EE
Home
Album
Mine

09:49 5G 73

Add Device

Select Model

Vcore Series

Vcore

Pyro Series

Pyro 7、Pyro S、Pyro H

Mars Series

Mars K4、Mars M1、Mars M2、Mars 400S PRO II

Others

Mars 400、Mars 300+

09:49 5G 73

Add Device

Steps:
01 Power on the device and enter pairing mode
02 Enable Wi-Fi on your mobile device and connect to the hotspot starting with “HLD”
03 Once connected, real-time video monitoring will begin



Note:

Please ensure location services and data permissions are enabled,If the device hotspot is not found, try switching the channel.



2. Please after connect the Vcore, please wait for some time. The iPhone will display a pop-up window prompting you to choose between Wi-Fi and cellular data. Please select cellular data.



3. Enter the setting menu



4. Find the Device Info.



5. Select Version Update



6. After download,select the upgrade.The product will enter the upgrading process.

6. After upgrading，Please restart the Vcore.

*** Attention：Please make sure Vcore having enough battery when upgrading.**

Using HollyView APP to upgrade Vcore on Android

Use your phone to connect the wifi of the Vcore

(1)The wifi name of the Vcore is HLD_xxxxx,the default password is 12345678

(2)Or you can use the HollyView app to scan the QR code of the product to connect the wifi.


15:21
5G
62
Home
My Devices
Pyro S
WiFi:HLD_3322375
Vcore
WiFi:HLD_000FA8D
MARS 400S PRO
WiFi:HLD_E0008EE
Vcore
WiFi:HLD_37170B8
Home
Album
Mine

(3) Add new product and select Vcore.


09:49
5G
73
Home
My Devices
Vcore
WiFi:HLD_38224QA
Pyro S
WiFi:HLD_3322375
Vcore
MARS 400S PRO


WiFi:HLD_000FA8D
WiFi:HLD_E0008EE
Home
Album
Mine

09:49 5G 73

Add Device

Select Model

Vcore Series

Vcore

Pyro Series

Pyro 7、Pyro S、Pyro H

Mars Series

Mars K4、Mars M1、Mars M2、Mars 400S PRO II

Others

Mars 400、Mars 300+

09:49 5G 73

Add Device

Steps:
01 Power on the device and enter pairing mode
02 Enable Wi-Fi on your mobile device and connect to the hotspot starting with “HLD”
03 Once connected, real-time video monitoring will begin



Note:

Please ensure location services and data permissions are enabled,If the device hotspot is not found, try switching the channel.



2. Disconnect the phone from Vcore.
3. Exit the HollyView APP and clear the background Hollyview app.



4. Connect a Wi-Fi which can connect to internet.Open HollyView again.
5. The HollyView will detect a new version. Please download it.

14:06
5.50 KB/s
78
Home
HOLLYLAND
微影
即拍即传，无线分享
Discover New Version
Download the firmware in advance to upgrade instantly when connected
Vcore
Version Details >
Don’t remind me again
Cancel
Download



6. Connect the Vcore's Wi-Fi. Enter monitor page. Then the upgrade will begin.



Using USB flash driver to upgrade Vcore

Precautions

- The USB flash drive must have a capacity of 32GB or less. Otherwise, the USB flash drive cannot be formatted into FAT32 format.
- Maintain sufficient power during the upgrade process. Do not pull out the USB flash drive before the upgrade is successful.
- After the device is upgraded, the default settings are restored.
- **Upgrade may cause unknown errors. Avoid upgrading when you need to use it.**

Vcore upgrade procedure

1. Go to the network disk link provided on the page to download the firmware package.
2. Prepare a USB flash disk with a capacity of no more than 32GB Type-C interface. If it is not Type-C interface, use the standard USB Type-C adapter to connect.

3. Connect the USB flash drive to the computer. By formatting, set the format of the USB flash drive to FAT32. Place the upgrade files directly in the root directory of the USB flash drive. Do not create them in the folder.
4. Connect the USB flash drive to the Type-C interface of Vcore. The system automatically recognizes the USB flash drive, restarts the image transmission, and then starts the upgrade. After the upgrade is completed, the image transmission will restart again.

Windows how to set the USB flash disk format



Copy the OTA file into the root directory



How to Set USB flash driver format for Mac computer



If the upgrade fails multiple times or an exception occurs during the upgrade, contact the technical support staff of Hollyland.